

Over time the gaskets (rubber seals) on your Zing Anything bottles may trap food particles and liquid residue. Zing Anything recommends periodic cleaning of both the top lid gasket and the bottom cup gasket. The process is simple and can be performed with a toothpick or similar item. Gaskets can be hand-washed with soap and water or added to the top rack of your dishwasher along with your Zing Anything product.

### BOTTOM GASKET REMOVAL

The method for removing the bottom gasket is the same for every Zing Anything product. It is important to note the gasket orientation before you begin. If the gasket is replaced upside down, the bottle may leak.



1  
With the bottle turned upside down, insert a toothpick between the gasket and the bottle.


2  
Gently pull the gasket away from the bottle until you can grasp it with your fingers.

3  
Slowly remove the gasket, taking care not to stretch the rubber more than necessary.

### BOTTOM GASKET REPLACEMENT

After cleaning, it is very important to return the bottom gasket to its original position. The illustration below shows its correct orientation. Note that the ridges should always face outward and the wider part of the gasket should rest on the lip of the bottle.

Carefully replace gasket, again making sure not to stretch the rubber more than necessary.




Gasket orientation is the same for all Zing Anything products

### TOP GASKET REMOVAL

The Citrus Zinger top gasket can be easily removed with the fingers. The Aqua Zinger and Vodka Zinger top gaskets must be removed with a toothpick or tweezers prevent damage. The Salad Zinger does not use a top gasket.

The Aqua Zinger double loop cap gasket can be easily removed with a toothpick using the same method for the bottom gasket.

The Aqua Zinger sport cap may require the use of tweezers. Using a pair of tweezers, gently pull up on the gasket in a few different places, until the gasket starts to rise up from the channel. Once you can grab the gasket firmly with the tweezers, carefully pull it out.



### TOP GASKET REPLACEMENT

The Citrus Zinger top gasket can be pushed back into place with your fingers. Use a toothpick to push the outer edge of the gasket into the channel. Once the gasket is in place, screw the cap back on tightly to ensure it's proper placement.

The Aqua Zinger and Vodka Zinger double loop cap gasket can be easily replaced with your fingers.

The Aqua Zinger sport cap gasket can be replaced with your fingers, however you may need to use tweezers or a toothpick to push the gasket completely into its channel.

## CAUTIONS AND WARNINGS

- Do not use sharp instruments to remove gaskets as they may cause damage
- Ensure that gaskets are replaced correctly to prevent leaking
- Do not stretch gaskets more than necessary
- Do not use damaged gaskets
- Do not use your Zing Anything product if gaskets are not installed